

Temporary Bug Fix for COSELICA 0.4.9

The parameter descriptions of some obsolete blocks (MMT_Spring, MMT_SpringDamper, and MMR_SpringDamper) in the Right-Click | Open/Set dialog are mixed up.

The correct order for the parameters in the setup dialogs are:

MMT_Spring:

1. s_rel0
2. c

MMT_SpringDamper:

1. s_rel0
2. c
3. d

MMR_SpringDamper:

1. c
2. phi_rel0
3. d

You should not use these blocks in new diagrams anyway, replace them by CMT_C_Spring¹, CMT_C_SpringDamper², or CMRC_SpringDamper³.

Apart from the above, old diagrams containing MMT_Spring, MMT_SpringDamper, or MMR_SpringDamper should work as expected.

¹Coselica.Mechanics.Translational.Components.Spring

²Coselica.Mechanics.Translational.Components.SpringDamper

³Coselica.Mechanics.Rotational.Components.SpringDamper